

DA-E560

# Wireless Audio with Dock

## user manual

imagine the possibilities

Thank you for purchasing this Samsung product.  
To receive more a complete service,  
please register your product at  
[www.samsung.com/register](http://www.samsung.com/register)

**SAMSUNG**

# features

---

## **Galaxy Docking Audio Speaker System**

Using the system's docking station, dock, charge, and then play any Samsung Galaxy devices through the system's built-in speakers.

## **aptX®**

aptX enables high quality Bluetooth stereo audio, delivering wired audio quality wirelessly.

# safety information

ENG

## SAFETY WARNINGS

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER(OR BACK).  
NO USER-SERVICEABLE PARTS ARE INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This symbol indicates “dangerous voltage” inside the product that presents a risk of electric shock or personal injury.



This symbol indicates important instructions accompanying the product.

**WARNING :** To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.


**CAUTION :** TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

- This apparatus shall always be connected to a AC outlet with a protective grounding connection.
- To disconnect the apparatus from the mains, the plug must be pulled out from the mains socket, therefore the mains plug shall be readily operable.


### CAUTION

- Do not expose this apparatus to dripping or splashing. Do not put objects filled with liquids, such as vases on the apparatus.
- To turn this apparatus off completely, you must pull the power plug out of the wall socket. Consequently, the power plug must be easily and readily accessible at all times.


## PRECAUTIONS




Ensure that the AC power supply in your house complies with the power requirements listed on the identification sticker located on the back of your product. Install your product horizontally, on a suitable base (furniture), with enough space around it for ventilation (70~100 mm). Make sure the ventilation slots are not covered. Do not place the unit on amplifiers or other equipment which may become hot. This unit is designed for continuous use. To fully turn off the unit, disconnect the AC plug from the wall outlet. Unplug the unit if you intend to leave it unused for a long period of time.



During thunderstorms, disconnect the AC plug from the wall outlet. Voltage peaks due to lightning could damage the unit.




Do not expose the unit to direct sunlight or other heat sources. This could cause the unit to overheat and malfunction.



Protect the product from moisture (i.e. vases), and excess heat (e.g. fireplaces) or equipment creating strong magnetic or electric fields. Disconnect the power cable from the AC supply if the unit malfunctions. Your product is not intended for industrial use. This product is for personal use only.

Condensation may occur if your product has been stored in cold temperatures. If transporting the unit during the winter, wait approximately 2 hours until the unit has reached room temperature before using.



The batteries used with this product contain chemicals that are harmful to the environment.

Do not dispose of batteries in the general household trash.

# contents

ENG



<b>FEATURES</b>	2	Features
<b>SAFETY INFORMATION</b>	3	Safety warnings
	4	Precautions
<b>GETTING STARTED</b>	6	Before reading the user's manual
	6	What's included
<b>DESCRIPTIONS</b>	7	Front/Rear Panel
<b>REMOTE CONTROL</b>	9	Tour of the remote control
<b>POWER ON AND VOLUME CONTROL</b>	10	Turning the Power on/off
	10	Adjusting the volume
<b>CONNECTIONS</b>	11	Using Rubber
	12	Connecting a device to the Galaxy Dock
	13	Connecting an audio device using AUX IN
	15	Connecting to Bluetooth devices
<b>PLAYING</b>	16	Using the docking mode with Samsung Galaxy Devices
	17	Using the Bluetooth mode
<b>FUNCTIONS</b>	18	Advanced functions
<b>TROUBLESHOOTING</b>	19	Troubleshooting
<b>APPENDIX</b>	20	Specifications

# getting started

## BEFORE READING THE USER'S MANUAL

Note the following terms before reading the user manual.

### Icons used in this manual

Icon	Term	Definition
	<b>Caution</b>	Indicates a situation where a function does not operate or settings may be canceled.
	<b>Note</b>	Indicates tips or instructions on the page that help a function operate.

### Safety Instructions and Troubleshooting

- 1) Familiarise yourself with the Safety Instructions before using this product. (See page 3)
- 2) If a problem occurs, check Troubleshooting. (See page 19)






### Copyright

©2012 Samsung Electronics Co.,Ltd.

All rights reserved; no part or whole of this user's manual may be reproduced or copied without the prior written permission of Samsung Electronics Co.,Ltd.

## WHAT'S INCLUDED

Check for the supplied accessories shown below.


		
Remote Control / Lithium Battery (3V)	Power Adapter	User Manual
		
Rubber-Support / Rubber-Skin	Cloth	




- The appearance of the accessories may differ slightly from the illustrations above.

## FRONT/REAR PANEL

<FRONT>



<REAR>



<b>1</b>	<b>BASS</b>	Optimise the sound based on your tastes.
<b>2</b>	<b>VOLUME +/-</b>	Controls the volume level.
<b>3</b>	<b>PLAY/PAUSE</b>	Play or pause a music file.
<b>4</b>	<b>GALAXY DOCK</b>	Provides a 5-pin dock for Samsung Galaxy devices.
<b>5</b>	<b>STANDBY LED</b>	The standby LED lights up in standby mode. The standby LED turns off when the power of the unit turned on.
<b>6</b>	<b>REMOTE CONTROL SENSOR</b>	The remote control sensor which receives signals from the remote control.
<b>7</b>	<b>DC 12V</b>	Connect the unit's DC adapter to this jack.
<b>8</b>	<b>AUX IN</b>	Connect to the Analog output of an external device.



- When you turn on this unit, there will be a 4 to 5 second delay before it produces sound.




- This unit can connect to mobile devices with high audio output levels. When you connect this unit to external devices with high output levels, it may lower the audio output to protect the amp and speakers.
- When disconnecting the power cable from the wall outlet, hold the plug.  
Do not pull the cable.



# remote control


ENG

## TOUR OF THE REMOTE CONTROL



● REMOTE CONTROL

### Installing battery in the Remote Control



1. Open the cover of the remote control by putting your fingernail into the gap between the cover and body of the remote control. Then, lift the cover and separate it completely.

2. Install a 3V Lithium battery. Insert the battery into the battery compartment with the + side facing up.

3. Fit the remote control's cover to the remote control. Next, lower the cover so that it is flush with the body of the remote, and then press the cover into the body by pushing the edges down with your hand.




▪ Be careful not to catch your fingernail in the gap when you lift the cover. You can damage your fingernail.

### Operation Range of the Remote Control

You can use the remote control up to 23 feet (7 meters) in a straight line from the unit. You can also operate the remote at a horizontal angle of up to 30° from the remote control sensor.

# power on and volume control

## TURNING THE POWER ON/OFF



1. To turn on this unit, touch any button on the unit's front panel when the unit is in Standby mode.

or,

Press **POWER** on the remote control.

2. To turn off this unit, touch the ►|| button on the unit's front panel for more than 3 seconds.

or,

Press **POWER** on the remote control again.




- The standby LED is on when AC Plug is connected to the wall outlet and the Power of the unit is off. The standby LED is off when the power of the unit is on.
- The power of the unit automatically turns off if there is no input for 20 minutes.

## ADJUSTING THE VOLUME

Use +, - buttons to adjust the volume. As you adjust the volume, the Input mode LED blinks.

The LED remains on in case you increase the volume when it has already been set to maximum, or decrease the volume when it has already been set to minimum.



Touch the +/- button on the right side of the front panel.

or,

Press **VOL +/-** on the remote control.




- The volume level increases or decreases when you press VOL +/-.
- You can also use the volume control of device connected using the Galaxy Dock or Bluetooth to control the volume. However, your ability to control the volume using the volume controls of devices connected using Bluetooth may be limited.

## USING RUBBER

Attach the Rubber to avoid direct contact with this set when you hold Samsung Galaxy Device.


### RUBBER-SUPPORT

1. Attach the Rubber to the proper place considering the size of the device which you want to use.
2. After attaching the Rubber-Support, dock your device on the Galaxy dock.



### RUBBER-SKIN


1. Cover the Rubber-Skin on the Galaxy dock.
2. After covering the Rubber-Skin on the Galaxy dock, dock your device on the Galaxy dock.



- Use the product after removing the Rubber-Skin attached to the product if you have the protection case for your device.
- You can use this product only when the thickness of the protection case is under 1.5mm when you attach the Spacer cover to your device. It is impossible to use this product when the thickness of the protection case is over 1.5mm or has special shape with round.

## CONNECTING A DEVICE TO THE GALAXY DOCK

How to connect a device to the Galaxy Dock.



1. The **GALAXY DOCK** is located on the front of the product. To open, push it in gently.

2. Connect your Samsung Galaxy device to the Galaxy Dock Connector.




- Turn on your Samsung Galaxy device before you docking it to the Galaxy Dock.
- Connect your Samsung Galaxy device to the Galaxy Dock before starting Docking mode. (See page 16)

## CONNECTING AN AUDIO DEVICE USING AUX IN

This section explains how to connect the unit to an audio device.

This unit is equipped with one audio analog jack for connecting an audio device.



### AUX IN

Connect AUX IN (Audio) on the back of the unit to the earphone jack of the external device or audio device.

**If connected to an external device via AUX input while your Samsung Galaxy device is docked or connected to a Bluetooth device at the same time, the input source switches between the AUX and Samsung Galaxy or Bluetooth device by tapping the PAUSE button on the Samsung Galaxy / Bluetooth device. Tap it again to switch to the other input source.**



- Use the Function key on the remote control to switch between connected devices, if there are multiple devices connected to the Docking station.
- Before moving or installing this product, be sure to turn off the power and disconnect the power cord.

## BLUETOOTH

---

You can connect the Wireless Audio with Dock to Bluetooth devices and enjoy music with high quality stereo sound, all without wires!

### What is Bluetooth?

---

Bluetooth technology lets Bluetooth-compliant devices interconnect easily with each other using a short wireless connection.

- A Bluetooth device may cause noise or malfunction, depending on usage, when:
  - A part of your body is in contact with the receiving/transmitting system of the Bluetooth device or the Wireless Audio with Dock.
  - It is subject to electrical variation from obstructions caused by a wall, corner, or by office partitioning.
  - It is exposed to electrical interference from same frequency-band devices including medical equipment, microwave ovens, and wireless LANs.
- Keep the Wireless Audio with Dock and the Bluetooth device close together when pairing.
- The further the distance between the Wireless Audio with Dock and Bluetooth device, the worse the quality. If the distance exceeds the Bluetooth operational range, the connection is lost.
- In poor reception-sensitivity areas, the Bluetooth connection may not work properly.
- The Bluetooth connection only works when the Bluetooth device is close to the set. The connection is automatically cut off if the Bluetooth device moves out of range. Even within range, the sound quality may be degraded by obstacles such as walls or doors.
- This wireless device may cause electric interference during its operation.




- You may be required to enter a PIN code (password) when connecting the Bluetooth device to the Wireless Audio with Docks. If the PIN code input window appears, enter <0000>.
- The Wireless Audio with Dock supports SBC data (44.1kHz, 48kHz).
- The AVRCP feature is not supported.
- Connect only to a Bluetooth device that supports the A2DP (AV) function.
- You cannot connect to a Bluetooth device that supports only the HF (Hands Free) function.
- Only one Bluetooth device can be paired at a time.
- Once you have turned off the Wireless Audio with Dock and the pairing is disconnected, the pairing will not be restored automatically. To reconnect, you must pair the devices again.
- The Wireless Audio with Dock may not search or connect properly in the following cases:
  - If there is a strong electrical field around the Wireless Audio with Dock.
  - If several Bluetooth devices are simultaneously paired to the Wireless Audio with Dock.
  - If the Bluetooth device is turned off, not in place, or malfunctions
  - Note that such devices as microwave ovens, wireless LAN adaptors, fluorescent lights, and gas stoves use the same frequency range as the Bluetooth device, which can cause electric interference.

## CONNECTING TO BLUETOOTH DEVICES


This section explains how to connect the Wireless Audio with Dock to Bluetooth compatible devices.

### To connect the Wireless Audio with Dock to a Bluetooth device

Before you begin, confirm that your Bluetooth device supports the Bluetooth compliant stereo headset function.



1. Select the Bluetooth menu on your Bluetooth device.  
(Refer to the Bluetooth device's user manual for instructions.)
2. Scan or search for All Devices or for Headsets.
  - You will see a list of devices.
3. Select "[Samsung]W\_Audio XXXXXX" from the searched list.
  - If the Bluetooth device fails to pair with the Wireless Audio with Dock, delete the "[Samsung]W\_Audio XXXXXX" found by the Bluetooth device, and search for the Wireless Audio with Dock again, and then repeat Steps 1, 2, and 3.



- When the AUX and Bluetooth operate at the same time as shown above, the sound may come from both simultaneously.

## USING THE DOCKING MODE WITH SAMSUNG GALAXY DEVICES

Connect the Samsung Galaxy device to the Galaxy Dock. (See page 12)


### <Samsung Galaxy Devices>

To use your Samsung Galaxy series device with the Galaxy Dock, you must download and install the Docking Mode application from the Android Market on the device. To download, follow these steps:

1. Tap the Play Store (Android Market) icon on the Samsung Galaxy device's main screen
2. Tap the search icon on the screen to access the search bar.
3. In the search bar, type in the **[Samsung Wireless Audio with Dock]**, and then search.
4. In the search result list, find, and then tap **[Samsung Wireless Audio with Dock]** to start downloading.
5. Tap **[install]**.



To play music, follow these steps:

- 1-1. If you start the app when the Wireless Audio with Dock is the only device for the Bluetooth connection, selecting **PLAY** in your device automatically establishes the Bluetooth connection to the Wireless Audio with Dock and the unit plays music.
- 1-2. If there are multiple devices for Bluetooth connection including the Wireless Audio with Dock,
  - 1) When you start the app, the list of the devices which you can connect to the Wireless Audio with Dock will appear.
  - 2) Play music after connecting to the Wireless Audio With Dock by selecting it on the list of devices.
    - If there exists a Bluetooth device paired to the Wireless Audio with Dock before, it will not appear in the list and be connected automatically.
2. If you replace the Wireless Audio with Dock which you have paired to your mobile device, you should delete the remaining settings saved in your device before pairing to the new one.
  -  → **[Clear data]**.



- Once you started the application, running is not disturbed by charging your mobile device with an ordinary charger.
- When you connect other device to the Wireless Audio with Dock after connecting Samsung Galaxy device in docking mode, you may have to turn off the Bluetooth mode of the Samsung Galaxy device.
- If you have trouble with connecting the Samsung Galaxy device to the Galaxy Dock, turn off the device's Bluetooth mode.



## USING THE BLUETOOTH MODE

Connect the Bluetooth device to the Wireless Audio with Dock. (See page 15)

To connect your Bluetooth device when the Wireless Audio with Dock is in Bluetooth mode, search for the Wireless Audio with Dock on the device's Bluetooth list. Select the Wireless Audio with Dock, and then connect. Once the Wireless Audio with Dock has connected, select and play the desired music.

The music will play through the Wireless Audio with Dock's speakers.



- If you want to change the device which is connected through Bluetooth mode to other device, disconnect the existing device and try to connect to the other device which you want to use.
- While in Bluetooth communication, Play/Pause/Next/Back operations may not be available depending on used mobile device and application.
- Operating Bluetooth device paired to the Wireless Audio with Dock may cause stuttering if operated while the Wireless Audio with Dock is playing back from AUX input.

### To disconnect the Bluetooth device from the Wireless Audio with Dock

You can cancel Bluetooth pairing from the Wireless Audio with Dock. For instructions, see the Bluetooth device's user manual.


- The Wireless Audio with Dock will be disconnected.



- The Bluetooth connection only works when the Bluetooth device is close to the set. The connection is automatically cut off if the Bluetooth device moves out of range. Even within range, the sound quality may be degraded by obstacles such as walls or doors.
- If the Bluetooth device comes back into the effective range, you can restart to restore the pairing with the Bluetooth device.

# functions

## ADVANCED FUNCTIONS




### Play/Pause

During playback, press the ►|| button.

- Press the ►|| button to stop playing the file temporarily. Press the ►|| button again to play the selected file.



- This function does not operate in Aux mode.



### Using function


Change the mode to switch to Docking and AUX sources.

Press **FUNCTION** on the remote control of this unit.

- Each time the button is pressed, the selection changes as follows : Galaxy (Bluetooth) → AUX mode



- Check the function you want to use by pressing the Function button on the remote control when multiple devices are connected to the product simultaneously.




### Skip Forward/Back

During playback, press the ◀◀, ▶▶ button.

- When there is more than one file and you press the ▶▶ button, the next file is selected.
- When there is more than one file and you press the ◀◀ button, the previous file is selected.




- This function does not operate in Aux mode.



### Muting the sound

This is useful when answering a doorbell or telephone call.

1. To mute sound of this unit, press the **MUTE** (⏏) button of the remote control.
2. Press **MUTE** (⏏) on the remote control again (or press **VOLUME +/-**) to restore the sound.



### Using the BASS function

Lets you optimise the bass sound according to your tastes.

Press **BASS** on the remote control of this unit.

- Each time the button is pressed, the selection changes as follows : BASS ON → OFF

# troubleshooting

ENG

Before requesting service, please check the following.

Symptom	Check	Remedy
The unit will not turn on.	<ul style="list-style-type: none"><li>• Is the power cord plugged into the outlet?</li></ul>	<ul style="list-style-type: none"><li>• Connect the power plug to the outlet.</li></ul>
A function does not work when the button is pressed.	<ul style="list-style-type: none"><li>• Has the Wireless Audio with Dock or the remote been exposed to static electricity?</li></ul>	<ul style="list-style-type: none"><li>• Disconnect the power plug and connect it again.</li></ul>
Sound is not produced.	<ul style="list-style-type: none"><li>• Is the unit properly connected to device?</li><li>• Is the Mute function on?</li><li>• Is the volume set to minimum?</li></ul>	<ul style="list-style-type: none"><li>• Connect it correctly.</li><li>• Press the Mute button to cancel the function.</li><li>• Adjust the volume.</li></ul>
The remote control does not work.	<ul style="list-style-type: none"><li>• Are the batteries drained?</li><li>• Is the distance between remote control and main unit too far?</li></ul>	<ul style="list-style-type: none"><li>• Replace with new batteries.</li><li>• Operate closer to the main unit.</li></ul>

● TROUBLESHOOTING

# appendix

## SPECIFICATIONS

<b>Model name</b>	DA-E560	
<b>GENERAL</b>	Weight	1.6 kg
	Dimensions (W x D x H)	462.7 x 151.8 x 122.3 mm
	Operating temperature range	+5°C~+35°C
	Operating humidity range	10 % to 75 %
<b>AMPLIFIER</b>	Rated output power	5W/CH, 4OHM, THD = 10%, 1kHz
	Input sensitivity/Impedance	800mV/20Kohm
	S/N ratio (analog input)	65 dB
	Separation(1kHz)	60 dB
<b>FREQUENCY RESPONSE</b>	Analog input	20Hz~22kHz(±3 dB)
<b>DOCKING RATING</b>	Galaxy	5 V 1.0 A

\* S/N ratio, distortion, separation, and usable sensitivity are based on measurement using AES (Audio Engineering Society) guidelines.

\* Nominal specification

- Samsung Electronics Co., Ltd reserves the right to change the specifications without notice.
- Weight and dimensions are approximate.
- For the power supply and Power Consumption, refer to the label attached to the product.



## Contact SAMSUNG WORLD WIDE

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care center.

Area	Contact Centre ☎	Web Site
<b>■ Asia Pacific</b>		
AUSTRALIA	1300 362 603	www.samsung.com
NEW ZEALAND	0800 SAMSUNG (0800 726 786)	www.samsung.com
CHINA	400-810-5858	www.samsung.com
HONG KONG	(852) 3698 4698	www.samsung.com/hk www.samsung.com/hk_en/
INDIA	1800 1100 11 3030 8282 1800 3000 8282 1800 266 8282	www.samsung.com
INDONESIA	0800-112-8888 021-5699-7777	www.samsung.com
MALAYSIA	1800-88-9999	www.samsung.com
PHILIPPINES	1-800-10-SAMSUNG(726-7864) for PLDT 1-800-3-SAMSUNG(726-7864) for Digitel 1-800-8-SAMSUNG(726-7864) for Globe 02-5805777	www.samsung.com
SINGAPORE	1800-SAMSUNG(726-7864)	www.samsung.com
THAILAND	1800-29-3232 02-689-3232	www.samsung.com
TAIWAN	0800-329-999 0266-026-066	www.samsung.com
VIETNAM	1 800 588 889	www.samsung.com
<b>■ Middle East</b>		
U.A.E	800-SAMSUNG (726-7864)	www.samsung.com
OMAN	800-SAMSUNG(726-7864)	www.samsung.com
KUWAIT	183-2255	www.samsung.com
BAHRAIN	8000-4726	www.samsung.com
Egypt	08000-726786	www.samsung.com
JORDAN	800-22273	www.samsung.com
IRAN	021-8255	www.samsung.com
Morocco	080 100 2255	www.samsung.com
Saudi Arabia	9200-21230	www.samsung.com
<b>■ Africa</b>		
NIGERIA	0800-726-7864	www.samsung.com
Ghana	0800-10077 0302-200077	www.samsung.com
Cote D' Ivoire	8000 0077	www.samsung.com
Senegal	800-00-0077	www.samsung.com
Cameroon	7095- 0077	www.samsung.com
KENYA	0800 724 000	www.samsung.com
UGANDA	0800 300 300	www.samsung.com
TANZANIA	0685 88 99 00	www.samsung.com
SOUTH AFRICA	0860-SAMSUNG(726-7864 )	www.samsung.com

